





# JUAL WHEN THE SUN DOESN'T SHINE



## INSTALLATION GUIDELINE




## JUAL ROOF CONSOLE (Cold roof - Board Based Surface)




# Symbol description



Drill Driver with a  $\varnothing 17$  socket



Manual handling



Torch



Pay attention!




Socket wrench with  
at 17 mm socket



Loosening operation  
(anti clock wise rotation)




$\varnothing 25$  mm hole saw



Tightening operation  
(clock wise rotation)

# JUAL Roof Console cold roof






# 1. Surface board drilling






Pay attention!  
The Hole Saw must be capable of sawing into the roofing membrane which may contain small pebbles.







## 2. Anchor / Adapter preassembly




1.




2.




3.



4.



5.




6.




# 3.

## Fixation of the Console with the Compression Ring



# 4.

## Roof Console Tightening



**Pay Attention!**  
The Connection Interface  
must be correctly aligned.





## 5. Torching

