




JUAL WHEN THE SUN DOESN'T SHINE



INSTALLATION GUIDELINE




JUAL ROOF CONSOLE (Cold roof - Wooden Rafter)

Symbol description



Drill Driver with a Ø6 mm wooden drill



Drill Driver with a TX40 bit driver



Gas torch



Manual handling



Pay attention!




Loosening operation
(anti clock wise rotation)




Tightening operation
(clock wise rotation)

JUAL Roof Console cold roof





1. Rafter predrilling



2. Fixation of the Console Adapter






Pay Attention
A standard wooden screw
should be used to fix the
Console Adapter against
rotational movement during the
installation.






Torx 40

3.

Fixation of the Console with the Compression Ring



4. Roof Console Tightening



Pay Attention
The Connection Interface
must be correctly aligned.





5. Torching

